

Black and White Video

Keywords / Key Phrases: black and white video

1. Please check the video produced by the webcam using our bundled applications, such as the Live! Cam Center or Webcam Center. Observe if the colors are still in black and white.
2. If the issue persists, uninstall the webcam drivers and applications from the **Add / Remove Programs** from the **Control Panel**.
3. Reinstall the drivers and applications using the bundled installation CD or check for updates/downloads by clicking on the **Downloads** link at the top right corner of this page under **Quick Links** and install them for your webcam.

Last updated: June 24th, 2009